



# AIRFLOW TENDON BOOTS FUR FRONT LEG SIZE CHART

The measurements are a guide to finding the correct size.

- Measure in cm by using a soft measuring tape.
- Make sure that your horse is in a relaxed state and is standing properly.

Measuring instructions:

- A** Measure the circumference of the horse's cannon.
- B** Measure the height from the top of the cannon to the widest part of the fetlock.

*Please note : The B measurements in the chart are the full measurements taken from the product (padding not included)*

Determine your horse's size by comparing the measurements in the chart to those of your horse's legs where the boots should sit.

SIZE OF BOOT		S	M	L
<b>A</b>	Circumference	18.5-23.5	19.5-25.5	21.5-28.5
<b>B</b>	Plastic Shell Height (at Centre Back)	19	20.5	21

Art.No. 2088

Measurements in cm