Perfect fit, maximum protection

It is important that your airbag fits pertectly in order to protect you as much as possible. A vest that is too tight could hurt you in the event of an explosion, on the other hand, a vest that is too loose might not be protective enough.

In the tables below you will find indications of measurements in cm relating to your bust, length shoulder to hip and your height. Once you have received the airbag, do the "hand test" by inserting it as in the photo. It is important to check that there is enough space for the 4 fingers. An optimal fit is important to ensure maximum airbag effectiveness.





A: chest size

B: length shoulder to hip

C: body height

FIND YOUR SIZE



Belair L2

Measures in cm	2XS	XS	S	M	L	XL	2XL	3XL
CHEST SIZE	65-80	75-85	75-90	80-90	85-95	90-100	95-105	100-115
LENGTH	25-30	27-32	30-35	32-37	32-37	35-40	37-42	37-42
BODY HEIGHT	145-160	145-160	145-165	165-175	170-185	180-190	180-190	180-190
CARTRIDGE	60 cc	60 cc	60 cc	60 cc	60 cc	85 cc	85 cc	85 cc



Belair / Éclair

Measures in cm	2XS	XS	S	M	L	XL/2XL	XL/2XL+	3XL
CHEST SIZE	65-80	75-85	75-90	80-90	85-95	90-100	95-105	100-115
LENGTH	25-30	27-32	30-35	32-37	32-37	35-40	37-42	37-42
BODY HEIGHT	145-160	145-160	145-165	165-175	170-185	180-190	180-190	180-190
CARTRIDGE	60 cc	60 cc	60 cc	60 cc	60 cc	85 cc	85 cc	85 cc



Oxair

Measures in cm	XS	S	M	L	XL/XXL
CHEST SIZE	75-85	75-90	85-95	90-100	95-110
LENGTH	27-32	30-35	32-37	35-39	39-42
BODY HEIGHT	145-155	145-165	170-180	175-185	180-190
CARTRIDGE	60 cc	60 cc	60 cc	60 cc	60 cc



Kids / Belkid L2

Measures in cm	T1	T2
CHEST SIZE	60-70	65-75
LENGTH	24-28	27-31
BODY HEIGHT	110-125	125-145
CARTRIDGE KIDS	30 cc	30 cc
CARTRIDGE BELKID L2	50 cc	50 cc